



INSTRUCTIONS



Materials needed: Grill
10mm socket w/ ratchet and extension
Needlenose pliers

Estimated Install time: about 1/2 hour

1. Start by removing the stock plastic guard from the grill area.
 - a. Remove the 10mm nuts from the area where indicated with **green arrows**. The side nuts will need to be removed from underneath.
 - b. Remove the push screws from the area where indicated with **green circles** (located under the car)
 - c. Slide the plastic guard piece out from behind and set aside.
2. Slide the grill mesh in from behind and center it into position.
3. Reinstall the plastic guard piece in the reverse of the removal. The center nut will need to be reinstalled from behind.