



## INSTRUCTIONS



Materials needed: Metal wire  
Wire Cutters

Estimated Install time: 30 minutes

1. Cut 2-4 pieces of wire into 6" sections.
2. Pop the hood and place the inserts over the stock grill.
3. Then feed the wire through 2 holes next to each other so the ends are behind the grill and twist once for a temporary hold.
4. Repeat this step around the grill. Try to keep them in the corners and middle for the most secure hold.
5. Repeat step 4 until you have all the wire ends through the insert.
6. Twist the wire tight up against the insert using your pliers.
7. Clip the ends of the wire about 3 winds up with your wire cutters and bend the ends into the mesh.