



Materials Needed: Grills (provided)  
Torx bit screwdriver  
Small Zip-ties (provided)  
Small Drill Bit  
Drill

Torx Screw

1. Top grill installation:

- Begin by taking out the old insert w/ the torx bit screwdriver.
- Remove the old insert and slide the new top insert in from the bottom up. Make sure the tabs (if available) are in place and that the torx screw goes back into the stock position.
- If the screw does not hold the mesh you can use a small washer behind the head of the screw to hold it on.

2. Bottom grill installation:

- The bottom inserts are held on with zip ties.
- You will need to drill six (6) small holes on the underside of the middle piece on the front fascia to run the zip ties through.

- The red dots are the locations of where the holes should be drilled from underneath.



- Here are some close-ups of the holes for the zip ties. The hole only has to go only through the bottom layer of the piece.



- A close-up of the zip tie



Just run the zip tie through the hole, around the mesh and tighten. Cut off the remaining length of zip tie. Do this for each hole that you drilled. If done correctly the zip ties are not visible from standing view.

Instructions were developed and written by a customcargrills.com customer. For questions regarding the installation of these grills please contact [mattkennedy@glade.net](mailto:mattkennedy@glade.net)

NOTE: Stock torx screws can be painted silver to provide a cleaner finished product.